

Seater Head 7,00/.284-R130

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R130
- Manufacturer: TRIEBEL
- Product no.: EU2017435
- Mfr. No.: 3000054V-07.00-R130
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R13
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R130

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R130. This product is designed for precise and gentle bullet seating, ensuring optimal performance in your reloading processes. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always use the Seater Head according to the manufacturer's instructions.
- Ensure that the product is compatible with your reloading dies before use.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any damage or wear before each use.
- Report any unsafe products or accidents to the relevant authorities.
- Check the EU's Safety Gate platform regularly for recall updates.

Specific Safety Precautions for Use

- Use protective eyewear when operating reloading equipment.
- Handle all reloading components with care to avoid accidental discharge.
- Ensure your workspace is clean and free from obstructions.
- Do not exceed the recommended load limits for your specific reloading setup.
- Always follow safe reloading practices as outlined in reloading manuals.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is securely mounted and stable.
- Select the correct Seater Head using the tool available on the manufacturer's website.
- Carefully install the Seater Head into the appropriate die, ensuring it is tightened securely.

2. Usage:

- Prepare your cartridges and ensure they are clean and free from debris.
- Place the bullet into the case mouth, aligning it with the Seater Head.
- Operate the reloading press smoothly to seat the bullet gently.
- Check for proper bullet seating depth and alignment after each operation.
- Store the Seater Head in a safe place when not in use to prevent damage.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Recycle packaging materials where possible.
- Ensure that all hazardous materials are disposed of safely.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or its usage, please refer to the manufacturer's website for support and additional resources.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,00/.284R130. Thank you for your attention to these important safety guidelines.