

Seater Head 7,00/.284-R135

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R135
- Manufacturer: TRIEBEL
- Product no.: EU2017436
- Mfr. No.: 3000054V-07.00-R135
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R13
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R135

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R135. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read all sections carefully before use to ensure your safety and the safety of others.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the product is used in a safe environment, free from hazards that could lead to accidents.
- Keep the Seater Head out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before each use.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the Seater Head.
- Ensure that the work area is welllit and free from clutter to minimize the risk of accidents.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Avoid using the Seater Head with incompatible or damaged reloading equipment.
- Never attempt to modify or alter the Seater Head as this may compromise its safety and effectiveness.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Carefully remove the Seater Head from its packaging.
- Insert the Seater Head into the appropriate die in your reloading press, ensuring a snug fit.
- Tighten any locking mechanisms to secure the Seater Head in place.

2. Usage:

- Verify that the correct seater head is selected for your specific cartridge by using the tool on the manufacturer's website.
- Set up your reloading press according to the manufacturer's instructions.
- Place the cartridge case in the press and ensure it is properly aligned.
- Slowly and gently operate the press to seat the bullet, ensuring consistent pressure for optimal results.
- After use, clean the Seater Head to remove any debris or residue.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal products.
- Do not dispose of the Seater Head in regular household waste.
- Consider recycling options for brass components where available.

Contact Information for Further Support

- For additional information or assistance, please refer to the manufacturer's website or contact your local

distributor.

By following these safety instructions, you can ensure the safe and effective use of the Seater Head 7,00/.284R135. Your safety is our priority, and we appreciate your commitment to responsible use.