

Seater Head 7,62/.30-K15,5

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-K15,5
- Manufacturer: TRIEBEL
- Product no.: EU2017439
- Mfr. No.: 3000054V-07.62-K15.5
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 15,5
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-K15.5

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 7,62/.30K15,5. This product is designed for precision bullet seating in reloading applications. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Always handle reloading components, including this product, in a safe and responsible manner.
- Keep this product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when handling reloading equipment.
- Use the Seater Head only with compatible Triebel dies to ensure proper functioning and safety.
- Avoid overtightening the Seater Head when installing it onto the die, as this may cause damage or malfunction.
- Do not modify the Seater Head or use it for purposes other than intended.
- Ensure that the work area is clean and free from obstructions while reloading.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Select the correct Seater Head using the tool available on the manufacturer's website: www.triebelreloading.com.
- Carefully screw the Seater Head into the corresponding die, ensuring it is securely fastened without overtightening.
- Check that the Seater Head is properly aligned with the die and that there are no obstructions.

2. Usage:

- Follow the reloading instructions provided with your specific die set.
- Load the cartridge case into the press and ensure it is positioned correctly.
- Operate the press slowly and steadily to seat the bullet. Avoid sudden movements that may affect accuracy.
- Inspect the seated bullets for proper alignment and depth after each use.

Disposal Instructions

- Dispose of any damaged or worn components of the Seater Head in accordance with local regulations.
- Do not dispose of reloading materials or components in regular household waste. Follow local guidelines for hazardous waste disposal.

Contact Information for Further Support

For further support regarding safety inquiries or product information, please refer to the manufacturer's website or contact their customer service directly.