

## Seater Head 7,62/.30-R20

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



### Attributes

- Name: Seater Head 7,62/.30-R20
- Manufacturer: TRIEBEL
- Product no.: EU2017440
- Mfr. No.: 3000054V-07.62-R020
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 20
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R020

# Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

# Seater Head Safety Instruction Guide

## Introduction

Thank you for choosing the Seater Head 7,62/.30R20. This product is designed to enhance your reloading experience by providing precision and consistency in bullet seating. To ensure your safety and the safe operation of this product, please read and follow the safety guidelines and instructions provided in this guide.

## General Safety Guidelines

- Ensure that you are familiar with the operation of reloading equipment before using the Seater Head.
- Always wear appropriate personal protective equipment, such as safety glasses and gloves, while handling reloading components.
- Keep the workspace clean and free from obstructions to prevent accidents.
- Store the Seater Head in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe conditions or accidents to the relevant authorities immediately.

## Specific Safety Precautions for Use

- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- Ensure that the Seater Head is properly secured to the reloading press before use.
- Do not exceed the recommended specifications for bullet seating, as this may lead to dangerous conditions.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- Always follow the manufacturer's instructions for the correct use of the Seater Head.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that the reloading press is turned off and unplugged.
- Remove any existing seater head from the press.
- Carefully install the Seater Head by threading it into the die body until it is snug.
- Check to ensure that it is securely fastened before proceeding.

### 2. Usage:

- Prepare your cartridges and ensure they are clean and free from obstructions.
- Set your reloading press to the appropriate settings for the specific caliber you are working with.
- Insert a cartridge case into the press and position the bullet above the case mouth.
- Gradually lower the press handle to seat the bullet gently into the case.
- Inspect the cartridge for proper bullet seating depth and alignment before proceeding with further reloading steps.

## Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations for hazardous waste.
- Do not dispose of the Seater Head in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

## **Contact Information for Further Support**

For any safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website or contact the appropriate support channels provided by the manufacturer.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,62/.30R20. Thank you for your attention to safety, and happy reloading!