

Seater Head 7,62/.30-R47

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R47](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017444
- Mfr. No.: 3000054V-07.62-R047
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 47
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R047

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R47. This guide provides essential safety instructions and usage information to ensure safe handling and optimal performance of your product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage.
- Always use the Seater Head in a wellventilated area to avoid inhalation of any dust or particles.
- Follow all manufacturer instructions for safe handling and operation.

Specific Safety Precautions for Use

- Use protective eyewear when operating the Seater Head to prevent any injury from flying debris.
- Ensure that your work area is clean and free from clutter to avoid accidents.
- Do not use the Seater Head if you are tired, under the influence of drugs or alcohol, or distracted.
- Keep hands and other body parts clear of moving parts during operation.
- If you experience any discomfort or unusual reactions while using the Seater Head, stop immediately and seek assistance.

Instructions for Installation and Usage

1. Installation:

- Ensure that you have the correct Seater Head for your specific die set.
- Carefully follow the instructions provided on the manufacturer's website to select the appropriate seater head.
- Securely attach the Seater Head to your reloading press according to the manufacturer's guidelines.

2. Usage:

- Adjust the Seater Head to the desired depth for bullet seating, ensuring it is set correctly before beginning.
- Load the cartridge case into the press and ensure it is properly aligned.
- Gently lower the Seater Head onto the bullet, applying steady pressure to seat the bullet correctly.
- After use, clean the Seater Head to remove any debris or residue.

Disposal Instructions

- Dispose of the Seater Head and any packaging materials in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or broken; contact local authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for support

resources and contact details.

By following these guidelines, you will help ensure a safe and effective reloading experience with the Seater Head 7,62/.30R47. Always prioritize safety and adhere to the instructions provided. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk