

Seater Head 7,62/.30-R62

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R62
- Manufacturer: TRIEBEL
- Product no.: EU2017448
- Mfr. No.: 3000054V-07.62-R062
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 62
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R062

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R62 from TRIEBEL. This guide provides essential safety instructions and guidelines to ensure the safe use of this product. Please read this document carefully before using the Seater Head to ensure your safety and the safety of others.

General Safety Guidelines

- Always follow the manufacturer's instructions for use and maintenance.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for signs of wear or damage before use.
- Report any unsafe conditions or product failures to the appropriate authorities.

Specific Safety Precautions for Use

- **Handling:** Handle the Seater Head with care to prevent injury. Use appropriate personal protective equipment (PPE) such as safety glasses and gloves.
- **Storage:** Store the Seater Head in a dry, cool place away from direct sunlight and moisture to prevent corrosion and damage.
- **Compatibility:** Ensure that the Seater Head is used only with original dies from Triebel Waffenwerkzeuge to avoid compatibility issues.
- **Cleaning:** Clean the Seater Head with a soft cloth and appropriate cleaning solutions. Avoid abrasive materials that may damage the surface.
- **Reloading Environment:** Always work in a wellventilated area and ensure that your reloading workspace is free of clutter and hazards.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Carefully remove the existing seater head if applicable.
- Install the Seater Head by following these steps:
 - Align the Seater Head with the die and thread it into place.
 - Tighten securely but do not overtighten to avoid damage.

2. Usage:

- Select the correct seater head using the tool on the manufacturer's website: www.triebelreloading.com.
- Adjust the seating depth according to your reloading specifications.
- Place the cartridge case in the reloading press and ensure it is securely held in place.
- Insert the bullet into the case mouth and activate the press to seat the bullet.
- Monitor the process closely to ensure proper bullet seating and alignment.

Disposal Instructions

- Dispose of the Seater Head responsibly at the end of its life cycle.
- Do not throw the product in regular household waste. Check local regulations for proper disposal methods for metal components.
- If the product is damaged or no longer usable, consider recycling it at a designated facility.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or safety instructions, please refer to the manufacturer's website for further support and information.

Remember to regularly check for updates on product recalls or safety notices through the EU's Safety Gate platform. Your safety is our priority, and we appreciate your commitment to using our products responsibly.