

Seater Head 7,62/.30-R65

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R65
- Manufacturer: TRIEBEL
- Product no.: EU2017449
- Mfr. No.: 3000054V-07.62-R065
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 65
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R065

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for purchasing the Seater Head 7,62/.30R65. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to avoid injury.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Do not use the Seater Head if it appears damaged or if you suspect it may be defective.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection and gloves, when using the Seater Head.
- Ensure that your working area is clean and free from distractions.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Use the correct seater head size for the specific bullet and cartridge you are working with.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head and ensure proper alignment.
- Be aware of your surroundings and ensure that no one is in close proximity while operating the reloading equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and properly set up.
- Select the appropriate Seater Head for your specific bullet and cartridge.
- Securely attach the Seater Head to the reloading die according to the manufacturer's instructions.

2. Usage:

- Prepare your cartridges and ensure that they are clean and properly sized.
- Insert the bullet into the cartridge case.
- Adjust the Seater Head to the desired seating depth as per your specifications.
- Slowly and gently operate the reloading press to seat the bullet. Monitor the seating process closely to ensure proper alignment.
- After seating, inspect the cartridge for proper bullet seating and alignment.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not throw the Seater Head in regular household waste. Check with local waste management for proper disposal methods.
- Recycle materials where possible, following local recycling guidelines.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's website or contact the supplier directly. It is important to have access to support for any questions or concerns about the Seater Head.

By adhering to these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,62/.30R65. Thank you for choosing our product, and happy reloading!