

Seater Head 7,62/.30-R70A

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R70A
- Manufacturer: TRIEBEL
- Product no.: EU2017451
- Mfr. No.: 3000054V-07.62-R070A
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 70A
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R070A

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R70A. This guide provides important safety information and usage instructions to ensure safe and effective operation of the product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling reloading equipment.
- Keep the Seater Head and all reloading components out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before each use.
- If you notice any defects or malfunctions, discontinue use immediately and contact the manufacturer.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible Triebel Waffenwerkzeuge dies.
- Always follow the manufacturer's instructions for installation and usage.
- Do not exceed the recommended pressure limits for your reloading setup.
- Avoid distractions while operating the Seater Head to maintain focus and ensure safety.
- Ensure proper ventilation in your workspace to avoid inhalation of any dust or particles generated during reloading.

Instructions for Installation and Usage

1. Installation

- Ensure that the reloading press is securely mounted and stable.
- Attach the Seater Head to the reloading die according to the manufacturer's instructions.
- Verify that the Seater Head is properly aligned and tightened to prevent movement during use.

2. Usage

- Adjust the seating depth according to the specifications of the bullets being used.
- Place the cartridge case in the reloading press and operate the press to seat the bullet.
- Monitor the process closely to ensure that the bullet is seated correctly and consistently.
- After use, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com for further assistance.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities. Please ensure that you follow these instructions carefully to maximize the performance and safety of your

Seater Head.