

Seater Head 7,62/.30-R70B

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R70B](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017452
- Mfr. No.: 3000054V-07.62-R070B
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 70B
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R070B

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R70B from TRIEBEL. This product is designed for highquality bullet seating in reloading applications. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recalls and safety updates through the EU Safety Gate platform.

Specific Safety Precautions for Use

• Hazard Identification:

- The Seater Head may have sharp edges; handle with care to avoid cuts.
- Ensure that your work area is clean and free from obstructions to prevent accidents.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Seater Head.

• Avoiding Hazards:

- Do not exceed the recommended specifications for your reloading equipment.
- Ensure that the Seater Head is securely attached to the reloading die before use.
- Avoid using excessive force when seating bullets to prevent damage to the product and ensure safety.
- Do not attempt to modify or alter the Seater Head in any way.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove the existing seater head from your reloading die, if applicable.
- Carefully insert the Seater Head 7,62/.30R70B into the reloading die, ensuring a snug fit.
- Tighten the seater head securely according to the manufacturer's specifications.

2. Usage:

- Prepare your cartridges and bullets according to standard reloading practices.
- Position the cartridge case in the reloading press.
- Place the bullet on top of the cartridge case.
- Slowly operate the reloading press to seat the bullet into the cartridge case.
- Check for proper alignment and seating depth before proceeding with further reloading steps.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations for metal recycling.
- Do not dispose of the product in general waste; check for specific disposal instructions for metal products in your area.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 7,62/.30R70B, please refer to the manufacturer's website or customer service resources for assistance.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk