

Seater Head 7,62/.30-R75

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R75](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017453
- Mfr. No.: 3000054V-07.62-R075
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 75
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R075

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R75. This product is designed for precision bullet seating, ensuring optimal performance in your reloading process. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to prevent damage and ensure longevity.
- Keep the product out of reach of children and vulnerable individuals.
- Always wear appropriate safety gear, such as safety glasses, when using reloading equipment.
- Be aware of your surroundings and ensure that your workspace is clean and free of hazards.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Before using the Seater Head, inspect it for any signs of damage or wear. Do not use if damaged.
- Ensure that the Seater Head is securely attached to the reloading die before use.
- Use the Seater Head only for its intended purpose – bullet seating.
- Avoid forcing the bullet into the case; this can lead to misalignment and unsafe conditions.
- Follow the manufacturer's guidelines for bullet types and weights compatible with the Seater Head.
- Always work in a wellventilated area to avoid inhalation of any dust or debris generated during reloading.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the die.
- Carefully insert the Seater Head 7,62/.30R75 into the die, ensuring it is aligned properly.
- Tighten the die securely according to the manufacturer's instructions.

2. Usage:

- Prepare your cartridges and bullets according to standard reloading practices.
- Place a cartridge case in the reloading press.
- Insert the bullet into the case mouth, ensuring it is seated straight.
- Activate the reloading press to seat the bullet using the Seater Head. Do not apply excessive force.
- Inspect the seated bullet for proper alignment and depth. Adjust as necessary.

Disposal Instructions

- Dispose of the Seater Head responsibly. If it is no longer usable, check local regulations for proper disposal methods.
- Do not dispose of the Seater Head in regular household waste.
- Consider recycling options for brass components if available in your area.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 7,62/.30R75, please refer to the manufacturer's

website or contact an authorized dealer for assistance.

By following these guidelines, you will ensure a safe and effective reloading experience with your Seater Head.
Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk