

Seater Head 7,62/.30-R85

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R85](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017454
- Mfr. No.: 3000054V-07.62-R085
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 85
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R085

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R85. This guide provides essential safety instructions and usage information to ensure your safe and effective use of this product. Please read this manual thoroughly before using the Seater Head.

General Safety Guidelines

- Ensure you are familiar with the product and its intended use.
- Always use the Seater Head in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, such as safety glasses and gloves, when using the Seater Head.
- **Work Area:** Use the Seater Head in a wellventilated area, free from distractions and hazards.
- **Handling:** Handle the Seater Head with care to avoid injury. Do not apply excessive force during use.
- **Compatibility:** Ensure that the Seater Head is compatible with your reloading dies. Use the tool on the manufacturer's website to select the correct seater head.
- **Storage:** Store the Seater Head in a dry and safe place when not in use to prevent damage.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials before starting.
- Ensure your workspace is clean and organized.

2. Installation:

- Remove the existing seater head from your reloading die.
- Carefully install the Seater Head 7,62/.30R85 into the die, ensuring it is securely fastened.
- Adjust the seater head to the desired depth according to your specific reloading requirements.

3. Usage:

- Follow the reloading process as per your reloading equipment instructions.
- Insert the bullet into the case mouth and align it properly.
- Gradually lower the ram to seat the bullet, ensuring optimal axial bullet alignment.
- Monitor the process to maintain cartridge concentricity and accuracy.

4. PostUse:

- After use, clean the Seater Head to remove any residue or debris.
- Store the Seater Head in its designated place to maintain its condition.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal waste.
- Do not dispose of the product in general waste. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com.

By following these safety instructions, you can ensure a safe and effective reloading experience. Thank you for your attention to safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk