

Seater Head 7,62/.30-R95

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R95
- Manufacturer: TRIEBEL
- Product no.: EU2017455
- Mfr. No.: 3000054V-07.62-R095
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 95
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R095

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R95. This guide provides essential safety instructions to ensure the safe use and handling of this product. Please read this guide carefully before use to maximize safety and performance.

General Safety Guidelines

- Ensure that you are familiar with the product and its intended use before operation.
- Always follow the manufacturer's instructions for installation and usage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe conditions or accidents to the relevant authorities.
- Stay informed about recall updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when handling the Seater Head.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Do not exceed the recommended specifications for bullet seating.
- Use only the recommended types of bullets and cartridges specified by the manufacturer.
- Keep your workspace clean and free from distractions during use.
- Avoid using the product if you are under the influence of drugs or alcohol.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged before installation.
- Carefully remove the Seater Head from its packaging.
- Align the Seater Head with the reloading die and secure it according to the manufacturer's instructions.
- Doublecheck that the Seater Head is firmly attached and properly aligned.

2. Usage

- Before loading, ensure that the reloading press is stable and secure.
- Load the cartridge case into the reloading press.
- Insert the bullet into the case mouth, ensuring proper alignment.
- Gradually apply pressure to the reloading press to seat the bullet.
- Monitor the seating depth and adjust as necessary to achieve desired specifications.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the product is damaged or no longer usable, follow local guidelines for hazardous waste disposal.
- Recycle components where possible, ensuring that they are clean and free from contaminants.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 7,62/.30R95, please refer to the manufacturer's website for further information and support.