

Seater Head 7,62/.30-R115

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R115
- Manufacturer: TRIEBEL
- Product no.: EU2017457
- Mfr. No.: 3000054V-07.62-R115
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 115
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R115

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R115. This product is designed for precise and gentle bullet seating, ensuring optimal performance. Please read this safety instruction guide carefully to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Always operate the product in a wellventilated area to avoid inhalation of any dust or particles.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the Seater Head.
- Ensure that the work area is clean and free of clutter to prevent accidents.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- Never exceed the recommended specifications for the Seater Head to prevent accidents and injuries.
- In case of malfunction or if the product appears damaged, discontinue use immediately and seek assistance.

Instructions for Installation and Usage

- **Installation:**

1. Ensure your reloading press is compatible with the Seater Head.
2. Remove any existing die from the reloading press.
3. Carefully screw the Seater Head into the press until it is securely fastened.
4. Adjust the height of the Seater Head according to your specific reloading requirements.

- **Usage:**

1. Select the correct seater head using the tool available on the manufacturer's website.
2. Prepare your cartridges and ensure they are clean and free of debris.
3. Insert the bullet into the cartridge case, ensuring proper alignment.
4. Slowly operate the reloading press to seat the bullet gently into the cartridge.
5. Inspect the cartridge to confirm proper bullet seating.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal products.
- Do not dispose of the product in regular household waste.
- Consider recycling the brass material if possible.

Contact Information for Further Support

For any safety inquiries or assistance, please refer to the manufacturer's website or customer support resources.

By following these guidelines and instructions, you can ensure safe and effective use of the Seater Head 7,62/.30R115. Thank you for your attention to safety.