

Seater Head 7,62/.30-R123

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R123](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017458
- Mfr. No.: 3000054V-07.62-R123
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 123
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R123

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 7,62/.30R123. This safety instruction guide is designed to help you use this product safely and effectively. Please read all sections carefully to ensure proper handling and operation.

General Safety Guidelines

- Always ensure that you are using the Seater Head in accordance with the manufacturer's recommendations.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that you are wearing appropriate safety gear, such as safety glasses, when using the Seater Head.
- Handle the Seater Head with care; avoid dropping or mishandling the product.
- Do not use the Seater Head if it is damaged or shows signs of wear.
- Follow all instructions for proper alignment and operation to avoid misfires or accidents.
- Ensure that the working area is clean and free of obstructions before using the Seater Head.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your workspace is clean and welllit.
- Gather all necessary tools and materials, including the Seater Head and compatible dies.

2. Installation:

- Carefully attach the Seater Head to the reloading die according to the manufacturer's instructions.
- Ensure that the Seater Head is securely fastened and properly aligned.

3. Usage:

- Load the cartridge case into the reloading press.
- Follow the manufacturer's guidelines for bullet seating, ensuring that the bullet is aligned correctly with the Seater Head.
- Operate the reloading press smoothly and steadily to ensure precise bullet seating.
- After use, remove the Seater Head and store it in a safe place.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- Check with local waste management authorities for proper disposal methods.

Contact Information for Further Support

For further assistance or inquiries regarding the Seater Head, please refer to the manufacturer's website or customer support resources.

Thank you for prioritizing safety while using the Seater Head 7,62/.30R123. By following these guidelines, you can ensure a safe and effective reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk