

Seater Head 7,62/.30-R125

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R125](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017459
- Mfr. No.: 3000054V-07.62-R125
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 125
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R125

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 7,62/.30R125. This product is designed for precision bullet seating in rifle reloading applications. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible reloading dies, specifically those from Triebel Waffenwerkzeuge.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the Seater Head and all reloading components out of reach of children and unauthorized users.
- Inspect the Seater Head for any damage or wear before each use. Do not use if damaged.
- Report any unsafe conditions or accidents to the appropriate authorities immediately.
- Check for recall updates on the EU's Safety Gate platform regularly.

Specific Safety Precautions for Use

- Do not exceed the recommended specifications for the Seater Head, including diameter and radius, as indicated in the product details.
- Use the Seater Head only for its intended purpose: bullet seating in rifle cartridges.
- Ensure that the workspace is clean and free from clutter to prevent accidents during use.
- Avoid loose clothing or accessories that could get caught in machinery.
- Always follow the manufacturer's instructions for the reloading process, including the proper setup of the Seater Head.
- Ensure that the Seater Head is securely attached to the reloading press before use.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the reloading die.
- Carefully insert the Seater Head into the die, ensuring it is seated properly.
- Tighten the set screw or locking mechanism to secure the Seater Head in place.

2. Usage:

- Set up your reloading press according to the manufacturer's guidelines.
- Insert the cartridge case into the press and align it with the Seater Head.
- Gradually lower the press handle to seat the bullet gently. Avoid using excessive force.
- Inspect each seated bullet for proper alignment and depth.
- After use, clean the Seater Head to remove any residue and ensure its longevity.

Disposal Instructions

- Dispose of any damaged or worn components responsibly according to local regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or its safe use, please refer to the manufacturer's website or customer service resources.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk