

Seater Head 7,62/.30-R130

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R130
- Manufacturer: TRIEBEL
- Product no.: EU2017460
- Mfr. No.: 3000054V-07.62-R130
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 130
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R130

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 7,62/.30R130. This product is designed for precise and gentle bullet seating, ensuring optimal performance and accuracy. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the Seater Head according to the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the Seater Head for damage before each use. Do not use if damaged.
- Store the Seater Head in a dry and safe place when not in use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that you are using the correct seater head for your specific reloading dies.
- Always wear appropriate safety gear, such as safety glasses and gloves, when handling reloading equipment.
- Avoid using excessive force when seating bullets, as this can lead to misalignment and potential hazards.
- Be aware of your surroundings and ensure that your workspace is clean and free of distractions.
- Do not exceed the recommended load limits for your specific application.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Remove any existing seater head from your reloading die.
- Carefully install the Seater Head 7,62/.30R130 into the die, ensuring it is properly seated.
- Tighten the seater head securely, but do not overtighten, as this may cause damage.

2. Usage:

- Prepare your cartridge case and bullet according to your reloading specifications.
- Place the cartridge case in the reloading press.
- Align the bullet with the cartridge case, ensuring proper seating alignment.
- Slowly and gently operate the reloading press to seat the bullet. Monitor for any resistance.
- After seating, inspect the cartridge for proper bullet alignment and seating depth.

Disposal Instructions

- Dispose of any damaged or unusable components in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Follow local guidelines for metal recycling.

Contact Information for Further Support

For any further inquiries or support regarding the Seater Head, please refer to the manufacturer's website or contact their customer service.

Thank you for prioritizing safety and compliance while using the Seater Head 7,62/.30R130. Your attention to these guidelines helps ensure a safe and effective reloading experience.