

Seater Head 7,62/.30-R145

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R145
- Manufacturer: TRIEBEL
- Product no.: EU2017461
- Mfr. No.: 3000054V-07.62-R145
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 145
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R145

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R145. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified by the manufacturer.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Keep the Seater Head and all reloading equipment out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding the use of reloading equipment.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use personal protective equipment (PPE) such as safety glasses and gloves when handling reloading equipment.
- Ensure that the work area is wellventilated and free of flammable materials.
- Do not exceed the recommended specifications for the Seater Head, as outlined by the manufacturer.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- Always doublecheck the compatibility of the Seater Head with your reloading dies before use.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials for the reloading process.
- Ensure that you have the correct Seater Head for your specific dies by using the tool available on the manufacturer's website.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Attach the Seater Head to your reloading die according to the manufacturer's instructions.
- Ensure that the Seater Head is securely fastened and properly aligned.

3. Usage:

- Load the cartridge case into the reloading press.
- Insert the bullet into the case mouth, ensuring proper alignment.
- Operate the reloading press to seat the bullet using the Seater Head.
- Monitor the process to ensure that the bullet is seated correctly and consistently.

Disposal Instructions

- Dispose of any unused or damaged Seater Heads in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in household waste. Check for recycling options for brass materials in your area.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Seater Head, please consult the manufacturer's website or contact their customer service directly.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,62/.30R145. Thank you for your attention to safety.