

## Seater Head 7,62/.30-R150

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



### Attributes

- Name: Seater Head 7,62/.30-R150
- Manufacturer: TRIEBEL
- Product no.: EU2017462
- Mfr. No.: 3000054V-07.62-R150
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 150
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R150

# Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

# Seater Head Safety Instruction Guide

## Introduction

Thank you for choosing the Seater Head 7,62/.30R150. This guide provides essential safety instructions and guidelines to ensure safe and effective use of the product. Please read and follow these instructions carefully to avoid accidents and ensure optimal performance.

## General Safety Guidelines

- Always use the Seater Head according to the manufacturer's instructions.
- Ensure that you are familiar with the operation of reloading equipment before using the Seater Head.
- Keep the Seater Head out of reach of children and unauthorized users.
- Inspect the Seater Head for any damages or defects before each use.
- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling ammunition components.
- Report any unsafe conditions or incidents to the relevant authorities immediately.
- Check for recall updates on the EU's Safety Gate platform to stay informed about product safety.

## Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading dies, specifically those from Triebel Waffenwerkzeuge.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Always work in a wellventilated area to avoid inhaling any dust or particles generated during the reloading process.
- Handle all components with care to avoid injury and ensure proper functioning.
- Do not modify the Seater Head or any associated equipment, as this may lead to unsafe conditions.
- Ensure that the reloading press is securely mounted and stable before beginning the reloading process.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure your reloading press is clean and free from debris.
- Select the appropriate Seater Head for your cartridge and ensure it matches the specifications.
- Securely install the Seater Head into the reloading press according to the manufacturer's instructions.
- Check that the Seater Head is properly aligned and tightened before use.

### 2. Usage:

- Prepare your cartridge cases and ensure they are clean and free from any obstructions.
- Place a bullet into the case mouth and align it with the Seater Head.
- Gradually apply pressure to the reloading press handle to seat the bullet into the case.
- Monitor the process closely to ensure proper bullet seating without excessive force.
- After use, clean the Seater Head and store it in a safe, dry location.

## Disposal Instructions

- Dispose of any used or damaged Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

## **Contact Information for Further Support**

For any inquiries or further assistance, please refer to the manufacturer's website or contact the relevant consumer support services in your region.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,62/.30R150. Thank you for prioritizing safety in your reloading activities.