

Seater Head 7,62/.30-R170

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R170](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017463
- Mfr. No.: 3000054V-07.62-R170
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 170
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R170

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R170. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read the entire guide before using the seater head to familiarize yourself with its features and safety measures.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified by the manufacturer.
- Always follow the operating instructions provided in this guide.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the seater head for any signs of damage or wear before each use.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recalls or safety alerts via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Handle the seater head with care to avoid injury.
- Use protective eyewear when operating the seater head to protect against debris.
- Ensure that the seater head is securely attached to the reloading die before use.
- Do not exceed the recommended specifications for the seater head to prevent malfunctions.
- Avoid using the seater head in damp or wet conditions to prevent rust and corrosion.
- Store the seater head in a dry, cool place when not in use.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading die is clean and free from debris.
- Align the seater head with the reloading die and gently screw it in until it is snug. Do not overtighten.
- Verify that the seater head is properly seated and aligned with the reloading die.

2. Usage:

- Prepare your cartridges and bullets according to the manufacturer's specifications.
- Place the cartridge case into the reloading die.
- Insert the bullet into the cartridge case, ensuring proper alignment.
- Operate the reloading press slowly and steadily to seat the bullet.
- Inspect the seated bullet for proper depth and alignment after each operation.

3. PostUsage:

- Clean the seater head after use to remove any residue or debris.
- Store the seater head in its designated storage container to prevent damage.

Disposal Instructions

- Dispose of the seater head in accordance with local regulations regarding metal recycling.
- Do not dispose of the seater head in regular household waste.
- If the product is damaged beyond use, ensure that it is safely disposed of to prevent any potential hazards.

Contact Information for Further Support

For any safety inquiries or support regarding the Seater Head 7,62/.30R170, please reach out to the manufacturer through their official website. It is important to have the product details on hand when seeking assistance.

Thank you for your attention to these safety instructions. Your safety is our priority, and following these guidelines will help ensure a safe and effective reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk