

Seater Head 7,62/.30-R220

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R220
- Manufacturer: TRIEBEL
- Product no.: EU2017464
- Mfr. No.: 3000054V-07.62-R220
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 220
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R220

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R220. This product is designed for precision bullet seating in reloading applications. To ensure your safety and the optimal performance of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Keep this product out of reach of children and vulnerable individuals.
- Always inspect the Seater Head for damage before use. Do not use if damaged.
- Use only with compatible dies and equipment to avoid malfunctions.
- When using the Seater Head, wear appropriate safety gear, such as safety glasses and gloves.
- Be aware of your surroundings and ensure you are in a safe environment while using this product.
- Follow all relevant local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- *Hazard Identification:*
 - Improper handling or installation may lead to injury or damage to the equipment.
 - Using the Seater Head with incompatible dies can result in malfunction.
- *Avoiding Hazards:*
 - Always ensure the Seater Head is securely attached to the die before use.
 - Do not force the bullet into the case; ensure proper alignment before seating.
 - Avoid wearing loose clothing or jewelry that could get caught in moving parts.
 - Keep your hands and other body parts clear of the die while operating.
- *Audience Specific Warnings:*
 - This product is not intended for use by individuals under 18 years of age.
 - Ensure that inexperienced users are supervised by a knowledgeable adult when using this product.

Instructions for Installation and Usage

- *Installation:*
 1. Ensure that the reloading press is turned off and unplugged before installation.
 2. Remove the existing Seater Head from the die if applicable.
 3. Carefully attach the Seater Head 7,62/.30R220 to the die, ensuring a secure fit.
 4. Tighten the Seater Head according to the manufacturer's specifications.
- *Usage:*
 1. Prepare your cartridge case and bullet according to your reloading manual.
 2. Insert the cartridge case into the die and ensure it is properly positioned.
 3. Place the bullet on the case mouth, aligning it with the Seater Head.
 4. Slowly operate the reloading press to seat the bullet. Monitor the process for alignment and resistance.
 5. After seating, check the cartridge for proper bullet seating depth and concentricity.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For safety inquiries or further assistance, please refer to the manufacturer's website or contact your local dealer.

By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head 7,62/.30R220. Thank you for your attention to safety.