

## Seater Head 7,91/.311-K8,5

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



### Attributes

- Name: [Seater Head 7,91/.311-K8,5](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017466
- Mfr. No.: 3000054V-07.91-K08.5
- Diameter (in): 0.311
- Diameter mm: 7,91
- Radius: K8,5
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.91-K08.5

# Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

# Seater Head Safety Instructions

## Introduction

Thank you for choosing the Seater Head 7,91/.311K8,5. This product is designed for precision bullet seating in reloading applications. To ensure safe and effective use, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified by the manufacturer.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Inspect the product regularly for any signs of wear or damage before use.
- Do not attempt to modify or repair the Seater Head; contact the manufacturer for assistance.
- Always use safety equipment, such as eye protection, when reloading ammunition.
- Be aware of your surroundings and ensure that you are in a safe environment when operating this product.

## Specific Safety Precautions for Use

- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Ensure that the Seater Head is securely attached to the reloading press before use.
- Avoid excessive force when seating bullets to prevent damaging the Seater Head or bullets.
- Do not exceed the recommended load specifications for the ammunition you are reloading.
- Store the Seater Head in a dry place to prevent corrosion.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure your reloading press is turned off and unplugged.
- Remove any existing seater head from your reloading die.
- Carefully screw the Seater Head into the die until it is snug.
- Adjust the seating depth as required for your specific bullet and cartridge.

### 2. Usage:

- Prepare your cartridge case and bullet as per your reloading specifications.
- Place the cartridge case into the shell holder of your reloading press.
- Insert the bullet into the case mouth, ensuring proper alignment.
- Activate the reloading press to seat the bullet into the case.
- Check the seated bullet for proper depth and alignment. Repeat as necessary.

## Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the product in regular household waste if it is damaged or worn.
- Consider recycling options for brass materials where applicable.

## Contact Information for Further Support

For any safety inquiries, product support, or to report unsafe products, please refer to the manufacturer's website or contact your local authorities. Always stay informed about product recalls and safety updates.

through the EU Safety Gate platform.

By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head 7,91/.311K8,5. Thank you for prioritizing safety in your reloading practices.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)