

Seater Head 7,92/.312-R50

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,92/.312-R50
- Manufacturer: TRIEBEL
- Product no.: EU2017467
- Mfr. No.: 3000054V-07.92-R050
- Diameter (in): 0.312
- Diameter mm: 7,92
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.92-R050

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Seater Head 7,92/.312R50](#)

Safety Instruction Guide for Seater Head 7,92/.312R50

Introduction

Thank you for choosing the Seater Head 7,92/.312R50, designed for precision bullet seating in reloading applications. This guide provides essential safety instructions to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Read and understand all instructions before using the product.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage to ensure safe operation.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection and gloves, when handling the Seater Head.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- Do not modify or alter the Seater Head in any way, as this may compromise its safety and performance.
- Ensure that the Seater Head is compatible with the original dies from Triebel Waffenwerkzeuge before use.
- Handle the product with care to avoid injury or accidents during reloading operations.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and free from debris.
- Carefully insert the Seater Head into the appropriate die according to the manufacturer's instructions.
- Tighten the Seater Head securely to prevent movement during use.

2. Usage:

- Adjust the Seater Head to the desired seating depth according to your specific reloading requirements.
- Place the cartridge case in the reloading press and ensure it is properly aligned.
- Operate the press slowly and steadily to ensure gentle bullet seating.
- Monitor the seating process to ensure optimal axial bullet alignment and cartridge concentricity.

3. PostUse:

- After use, clean the Seater Head to remove any residue or debris.
- Store the Seater Head in a safe and dry location, away from children and pets.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for recycling programs or hazardous waste disposal options in your area.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 7,92/.312R50, please refer to the manufacturer's website for additional resources and support.