

Seater Head 7,92/.312-R60

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,92/.312-R60](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017468
- Mfr. No.: 3000054V-07.92-R060
- Diameter (in): 0.312
- Diameter mm: 7,92
- Radius: R60
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.92-R060

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,92/.312R60. This guide provides essential safety information and instructions to ensure the safe and effective use of your product. Please read this guide carefully before using the Seater Head and keep it for future reference.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Always inspect the Seater Head for signs of damage or wear before each use.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses, when using the Seater Head.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Ensure that the working area is clean and free from obstructions before starting your reloading process.
- Avoid using the Seater Head in wet or damp conditions to prevent electrical hazards.
- Do not force the Seater Head; if it does not fit properly, stop and check compatibility.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Select the appropriate Seater Head for your specific cartridge, using the tool on the manufacturer's website.
- Carefully attach the Seater Head to the reloading die, ensuring a snug fit.
- Check that all components are properly aligned and tightened before use.

2. Usage:

- Prepare your workspace by laying out all necessary components and tools.
- Follow the reloading instructions specific to your cartridge to ensure safe operation.
- Monitor the seating process closely to maintain accurate bullet alignment.
- After use, clean the Seater Head to remove any debris or residue.

Disposal Instructions

- Dispose of the Seater Head responsibly, following local regulations for metal recycling.
- Do not dispose of the Seater Head in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety, product compatibility, or other concerns, please refer to the manufacturer's website or contact your local distributor.

Please remember that safety is paramount when using any reloading equipment. By following these guidelines,

you can help ensure a safe and efficient reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk