

Seater Head 8,08/.318-R15

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,08/.318-R15](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017470
- Mfr. No.: 3000054V-08.08-R015
- Diameter (in): 0.318
- Diameter mm: 8,08
- Radius: R15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.08-R015

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,08/.318R15. This product is designed for precision bullet seating and is manufactured from highquality brass using modern CNC machines. It is important to read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always ensure that you are using the Seater Head in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Be aware of your surroundings and ensure a safe working environment when using this product.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- Ensure that your reloading equipment is in good working condition before use.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head and ensure consistent results.
- Always wear appropriate safety gear, such as safety glasses, when handling reloading equipment.
- Do not use the Seater Head for any purpose other than intended.

Instructions for Installation and Usage

1. Selection of Seater Head:

- Use the tool available on the manufacturer's website (www.triebelreloading.com) to select the correct seater head for your needs.

2. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Insert the Seater Head into the appropriate die and tighten it securely according to the manufacturer's specifications.

3. Usage:

- Place the cartridge case into the reloading press.
- Align the bullet with the Seater Head and apply gentle pressure to seat the bullet.
- Monitor the process to ensure proper alignment and seating depth.

4. PostUse Care:

- After use, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in a safe, dry place away from direct sunlight and moisture.

Disposal Instructions

- Dispose of any damaged or worn components of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Check for local recycling options or hazardous waste disposal guidelines.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website for contact details.

By following these safety instructions, you can help ensure a safe and effective reloading experience with the Seater Head 8,08/.318R15. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk