

Seater Head 8,15/.321-K8

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,15/.321-K8](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017471
- Mfr. No.: 3000054V-08.15-K08
- Diameter (in): 0.321
- Diameter mm: 8,15
- Radius: K8
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.15-K08

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,15/.321K8. This product is designed for precise and gentle bullet seating in reloading applications. To ensure safe and effective use, please read this safety instruction guide carefully before using the product.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions to prevent accidents and injuries.
- Ensure that the product is compatible with your reloading equipment and dies.
- Inspect the Seater Head for any damage or defects before use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Do not exceed the recommended specifications for bullet diameter and reloading parameters.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Seater Head.
- Ensure that the workspace is clean and free from obstructions to avoid accidents.
- Use the Seater Head only in a wellventilated area to minimize exposure to any fumes or dust created during reloading.
- Follow all local laws and regulations regarding ammunition reloading and handling.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the die.
- Carefully install the Seater Head 8,15/.321K8 into the die, ensuring it is securely fastened.
- Check that the seater head is correctly aligned and adjusted according to your specific reloading setup.

2. Usage:

- Set the desired bullet seating depth based on your reloading specifications.
- Insert the cartridge case into the reloading press.
- Place the bullet on top of the case and engage the press to seat the bullet.
- Monitor the process closely to ensure proper alignment and seating of the bullet.
- If you encounter any resistance or issues, stop immediately and inspect the setup before proceeding.

Disposal Instructions

- Dispose of the Seater Head and any related materials in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or contains hazardous materials.
- Consider recycling options for metal components if available.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or safety guidelines, please refer to the manufacturer's website for further assistance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk