

Seater Head 8,17/.322-R15

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,17/.322-R15
- Manufacturer: TRIEBEL
- Product no.: EU2017473
- Mfr. No.: 3000054V-08.17-R015
- Diameter (in): 0.322
- Diameter mm: 8,17
- Radius: R15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.17-R015

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,17/.322R15. This product is designed for precision bullet seating and is made from highquality brass, ensuring durability and accuracy. This safety instruction guide provides essential information to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand the safety instructions before using the Seater Head.
- Ensure that the Seater Head is compatible with your reloading equipment and original dies from Triebel Waffenwerkzeuge.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for signs of wear or damage before each use.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use the Seater Head only for its intended purpose—bullet seating.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the Seater Head.
- Ensure that the work area is clean, dry, and welllit to prevent accidents.
- Do not exceed the recommended specifications for bullet diameter and caliber.
- Follow the manufacturer's guidelines for bullet seating depth and pressure limits to avoid dangerous conditions.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Carefully remove the Seater Head from its packaging.
- Align the Seater Head with the die in your reloading press.
- Secure the Seater Head in place according to the manufacturer's instructions.

2. Usage:

- Prepare your cartridges and bullets as per your reloading procedure.
- Adjust the Seater Head to the desired seating depth by following the manufacturer's guidelines.
- Place the bullet into the cartridge case and position it under the Seater Head.
- Activate the reloading press to seat the bullet gently into the case.
- Inspect each cartridge after seating to ensure proper alignment and depth.

Disposal Instructions

- Dispose of the Seater Head responsibly when it is no longer in use.
- Follow local regulations for the disposal of metal products.
- Do not throw the Seater Head in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's website at www.triebelreloading.com.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 8,17/.322R15. Thank you for your attention to safety, and happy reloading!