

Seater Head 8,20/.323-K15

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,20/.323-K15
- Manufacturer: TRIEBEL
- Product no.: EU2017476
- Mfr. No.: 3000054V-08.20-K15
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: K15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-K15

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,20/.323K15 by TRIEBEL. This guide provides essential safety instructions to ensure the safe use and handling of your product. Please read this guide carefully before installation and usage.

General Safety Guidelines

- Always follow manufacturer instructions for safe use.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recall updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves while handling the Seater Head.
- Ensure the work area is clean and free from obstructions to prevent accidents.
- Avoid using the Seater Head if it appears damaged or has been modified in any way.
- Do not exceed the recommended specifications for diameter and radius as indicated in the product details.
- Always ensure that the bullet seating process is performed in a wellventilated area to avoid inhalation of any particles.
- Follow all local regulations regarding the handling and disposal of ammunition components.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials.
- Ensure your reloading equipment is compatible with the Seater Head specifications.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Inspect the Seater Head for any damage.
- Securely attach the Seater Head to your reloading die as per the manufacturer's instructions.

3. Usage:

- Adjust the Seater Head to match the specific bullet profile for optimal performance.
- Insert the cartridge case into the reloading press.
- Gently lower the Seater Head onto the bullet to ensure proper seating.
- Monitor the process closely to maintain alignment and prevent misfires.

4. PostUsage:

- After use, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in a safe and dry location.

Disposal Instructions

- Dispose of any damaged or wornout parts in accordance with local regulations.
- Recycle packaging materials where possible.
- Do not dispose of the Seater Head or any associated components in regular household waste.

Contact Information for Further Support

For any inquiries or further support regarding the Seater Head, please refer to the contact information provided by the manufacturer on their official website. Always ensure you have the latest safety information and guidelines.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Seater Head 8,20/.323K15. Thank you for prioritizing safety in your reloading practices.