

Seater Head 8,20/.323-R43

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,20/.323-R43
- Manufacturer: TRIEBEL
- Product no.: EU2017477
- Mfr. No.: 3000054V-08.20-R043
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: R43
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-R043

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,20/.323R43. This guide provides essential safety instructions and precautions to ensure the safe use of your product. Please read this guide thoroughly before using the Seater Head to maximize safety and performance.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Store the Seater Head in a dry and secure location away from children and unauthorized users.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Avoid using the Seater Head if you are not familiar with its operation or if you are inexperienced with reloading.
- Always wear appropriate safety gear, including safety glasses, when using the Seater Head.
- Keep hands and other body parts clear of moving parts during operation.
- Ensure that the workspace is clean and free from clutter to prevent accidents.
- Do not exceed the recommended specifications for the Seater Head, including the diameter and radius.
- Use caution when handling bullets and cartridges to prevent injury.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Remove any existing seater head from the reloading die.
- Carefully install the Seater Head into the die, ensuring it is securely fastened.
- Confirm that the Seater Head is properly aligned with the die.

2. Usage:

- Prepare your cartridges and bullets according to the reloading guidelines.
- Adjust the Seater Head to the desired depth for bullet seating.
- Slowly and gently operate the reloading press to seat the bullet.
- After seating, check the cartridge for proper bullet alignment and depth.
- Store the Seater Head safely after use.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not throw away the Seater Head in regular household waste.
- Check with local recycling centers for proper disposal methods for brass and metal products.

Contact Information for Further Support

For any inquiries related to safety or product issues, please refer to the manufacturer's website or contact your local distributor for assistance.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the Seater Head 8,20/.323R43.