

Seater Head 8,20/.323-R45

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,20/.323-R45
- Manufacturer: TRIEBEL
- Product no.: EU2017478
- Mfr. No.: 3000054V-08.20-R045
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: R45
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-R045

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 8,20/.323R45. This product is designed to provide precision and accuracy for your reloading needs. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to prevent damage and ensure longevity.
- Keep the Seater Head and all reloading equipment out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before each use.
- Report any unsafe products or accidents to the appropriate authorities and check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading tools.
- Ensure the work area is clean, dry, and welllit to prevent accidents.
- Avoid distractions while using the Seater Head to maintain focus and precision.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Store the Seater Head in a safe place, preferably in its original packaging or a protective case, when not in use.

Instructions for Installation and Usage

1. **Preparation:** Before installation, ensure that you have the correct Seater Head for your reloading setup. Use the tool available on the manufacturer's website to verify compatibility.
2. **Installation:**
 - Remove any existing Seater Head from the die.
 - Clean the die threads to ensure a secure fit.
 - Carefully screw the new Seater Head into the die until it is securely fastened.
 - Ensure that the Seater Head is properly aligned and seated within the die.
3. **Usage:**
 - Set up your reloading press according to the manufacturer's instructions.
 - Insert the cartridge case into the press and ensure it is properly positioned.
 - Gently lower the Seater Head onto the bullet, applying consistent pressure to achieve proper seating.
 - Inspect the seated bullet for proper alignment and depth.
 - If necessary, make adjustments to the die settings to achieve the desired results.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Instead, check for local recycling programs or hazardous waste disposal sites.
- Ensure that all packaging materials are disposed of responsibly, following recycling guidelines where applicable.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or its usage, please refer to the manufacturer's website or contact their customer support for assistance.

Thank you for prioritizing safety and accuracy in your reloading practices. Enjoy your experience with the Seater Head 8,20/.323R45!