

Seater Head 8,20/.323-R50

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,20/.323-R50
- Manufacturer: TRIEBEL
- Product no.: EU2017479
- Mfr. No.: 3000054V-08.20-R050
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-R050

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,20/.323R50. This guide provides essential safety instructions and information to ensure the safe and effective use of this product. Please read this guide thoroughly before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading components.
- Store the Seater Head in a dry, cool place away from children and pets.
- Regularly inspect the Seater Head for any signs of wear or damage before each use.
- Follow all local laws and regulations regarding the use and storage of reloading equipment.

Specific Safety Precautions for Use

- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Ensure that the Seater Head is properly secured to the reloading press before use.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head or the bullet.
- Do not use the Seater Head with damaged or incompatible cartridges.
- Always keep your hands and body clear of the reloading press during operation.

Instructions for Installation and Usage

1. Installation

- Carefully unpack the Seater Head and inspect it for any damage.
- Locate the appropriate reloading press that is compatible with the Seater Head.
- Securely attach the Seater Head to the reloading press, following the manufacturer's instructions.
- Ensure that the Seater Head is aligned correctly for optimal performance.

2. Usage

- Prepare your cartridges according to the manufacturer's guidelines.
- Insert the bullet into the cartridge case.
- Adjust the reloading press settings according to the specifications for the Seater Head.
- Gently lower the press handle to seat the bullet. Avoid using excessive force.
- Inspect the cartridge for proper bullet seating and alignment after each operation.

Disposal Instructions

- Dispose of any unused or damaged Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in household waste. Instead, contact your local waste management authority for safe disposal options.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact your local dealer for assistance.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the Seater Head 8,20/.323R50. Always prioritize safety and consult the manufacturer for any additional information or support. Thank you for your attention to these important guidelines.