

Seater Head 8,20/.323-R50A

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,20/.323-R50A](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017480
- Mfr. No.: 3000054V-08.20-R050A
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: R50A
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-R050A

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for purchasing the Seater Head 8,20/.323R50A. This guide provides essential safety instructions to ensure the safe use, installation, and disposal of the product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose as specified by the manufacturer.
- Always follow the manufacturer's instructions for installation and usage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, while handling the Seater Head.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Ensure that the Seater Head is securely attached to the reloading die before use.
- Avoid using the Seater Head if it is damaged or if you notice any irregularities in its performance.
- Follow all local regulations regarding the handling and use of reloading equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that your workspace is clean and free from distractions.
- Verify that the Seater Head is compatible with your reloading die by checking the manufacturer's specifications.
- Carefully screw the Seater Head into the reloading die until it is secure.
- Doublecheck the alignment of the Seater Head to ensure it is straight and properly positioned.

2. Usage:

- Prepare your cartridges according to the manufacturer's guidelines.
- Place the cartridge case into the reloading press.
- Gently lower the Seater Head onto the bullet, ensuring it is aligned properly.
- Apply consistent pressure to seat the bullet into the cartridge case.
- Inspect the completed cartridge for proper seating and alignment.

Disposal Instructions

- Dispose of the Seater Head according to local regulations for metal recycling.
- If the product is damaged beyond repair, ensure it is disposed of in a manner that prevents any potential hazards to the environment or public safety.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please refer to the manufacturer's website or contact your local retailer for assistance.

By adhering to the guidelines outlined in this instruction manual, you can ensure the safe and effective use of the Seater Head 8,20/.323R50A. Always prioritize safety and compliance with relevant regulations during your reloading activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk