

Seater Head 8,20/.323-R75

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,20/.323-R75
- Manufacturer: TRIEBEL
- Product no.: EU2017482
- Mfr. No.: 3000054V-08.20-R075
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: R75
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-R075

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,20/.323R75. This product is designed for precision bullet seating and is made from highquality brass, ensuring durability and accuracy. To ensure your safety and the proper use of this product, please read this guide carefully.

General Safety Guidelines

- Always handle the Seater Head with care to prevent injury.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Always follow the manufacturer's instructions for use and maintenance.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Use only in accordance with the specifications provided by the manufacturer.
- Avoid using the Seater Head if it is damaged or shows signs of wear.
- Wear appropriate safety gear, such as safety glasses and gloves, when using the Seater Head.
- Do not exceed the recommended specifications for bullet seating as indicated by the manufacturer.
- Ensure that your workspace is clean and free from obstructions when using the Seater Head.
- Do not leave the Seater Head unattended while in use.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials.
- Ensure that your reloading equipment is clean and properly set up.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Check for any visible damage or defects.
- Install the Seater Head into the appropriate reloading die, ensuring a secure fit.

3. Usage:

- Select the correct seater head using the tool on the manufacturer's website: www.tribelreloading.com.
- Load the cartridge case into the reloading press.
- Follow the manufacturer's specifications for bullet seating depth and pressure.
- Perform the bullet seating operation, ensuring that the bullet is seated properly and uniformly.

4. PostUsage:

- After use, clean the Seater Head to remove any residue.
- Store the Seater Head in a safe and dry location, away from children.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of in regular household waste if it is damaged or contains hazardous materials.
- Consider recycling options for brass materials if available in your area.

Contact Information for Further Support

For any inquiries or support regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor. Always ensure you have the product details ready for efficient assistance.

Thank you for prioritizing safety and compliance while using the Seater Head 8,20/.323R75. Your attention to these guidelines helps ensure a safe and effective reloading experience.