

Seater Head 8,20/.323-R87

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,20/.323-R87
- Manufacturer: TRIEBEL
- Product no.: EU2017483
- Mfr. No.: 3000054V-08.20-R087
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: R87
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-R087

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,20/.323R87. This guide provides essential safety instructions to ensure the safe use of this product. Please read this guide carefully before using the seater head.

General Safety Guidelines

- Always ensure that the seater head is compatible with your reloading equipment.
- Inspect the seater head for any signs of damage before each use.
- Use the seater head only for its intended purpose as specified by the manufacturer.
- Keep the seater head out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- **Personal Protective Equipment (PPE):** Always wear safety glasses and gloves when handling the seater head to protect against debris and sharp edges.
- **Work Environment:** Ensure your work area is clean, welllit, and free of clutter to avoid accidents.
- **Handling:** Handle the seater head with care. Avoid dropping or mishandling it to prevent damage.
- **Storage:** Store the seater head in a secure, dry place when not in use to prevent corrosion and damage.
- **Compatibility Check:** Ensure that the seater head is suitable for the specific cartridge and bullet type you are using.

Instructions for Installation and Usage

1. Preparation:

- Confirm that the reloading die set is compatible with the Seater Head 8,20/.323R87.
- Ensure all necessary tools and materials are ready for the installation process.

2. Installation:

- Remove the existing seater head from the reloading die by unscrewing it in a counterclockwise direction.
- Carefully install the Seater Head 8,20/.323R87 by screwing it into the die in a clockwise direction until secure.
- Ensure the seater head is properly aligned and tightened to avoid any misalignment during use.

3. Usage:

- Set the reloading press to the correct position for bullet seating.
- Place the cartridge case into the press and insert the bullet into the case mouth.
- Gradually apply pressure to the press to seat the bullet, ensuring that it is aligned properly for optimal concentricity.
- Check each completed cartridge for proper seating depth and alignment before proceeding with further reloading steps.

Disposal Instructions

- Dispose of any damaged or wornout seater heads in accordance with local regulations.
- Do not throw the product in regular household waste. Check with local recycling programs for proper disposal methods.

Contact Information for Further Support

For safety inquiries or additional support, please refer to the manufacturer's website or contact your local retailer. Ensure you have the product details ready for a more efficient response.

Conclusion

Following these safety instructions will help ensure a safe and effective reloading experience with the Seater Head 8,20/.323R87. Always prioritize safety and compliance with local regulations. Thank you for your commitment to safe reloading practices.