

Seater Head 8,21/.323-R15

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,21/.323-R15
- Manufacturer: TRIEBEL
- Product no.: EU2017486
- Mfr. No.: 3000054V-08.21-R015
- Diameter (in): 0.323
- Diameter mm: 8,21
- Radius: R15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.21-R015

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,21/.323R15 from Triebel Waffenwerkzeuge. This guide provides important safety instructions and guidelines to ensure the safe and effective use of this product. Please read this document carefully before using the Seater Head.

General Safety Guidelines

- Always ensure that the Seater Head is compatible with your reloading equipment.
- Inspect the Seater Head for any visible damage before use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head only for its intended purpose, which is to seat bullets in cartridges.
- Follow all local laws and regulations regarding reloading and ammunition.
- Store the Seater Head in a safe and dry place when not in use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the reloading press is stable and securely mounted before using the Seater Head.
- Wear appropriate safety gear, including safety glasses and gloves, when handling reloading components.
- Do not exceed the recommended specifications for bullet seating to avoid potential hazards.
- Always doublecheck the bullet and cartridge specifications before seating.
- Be aware of the potential for lead exposure when handling bullets. Wash your hands thoroughly after use.
- Avoid distractions while reloading to maintain focus and precision.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged (if applicable).
- Remove any existing seater head from the press.
- Select the appropriate Seater Head from Triebel Waffenwerkzeuge, ensuring it matches your bullet diameter and specifications.
- Install the Seater Head by securely tightening it into the press according to the manufacturer's instructions.

2. Usage:

- Prepare your cartridge cases and bullets according to your reloading process.
- Insert a cartridge case into the reloading press.
- Place a bullet on top of the cartridge case.
- Operate the press to seat the bullet gently. Ensure that the bullet is aligned properly to avoid damage.
- Inspect the seated bullet for proper alignment and depth before proceeding with further reloading steps.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations.
- Do not throw the Seater Head in regular household waste. Check with local authorities for proper disposal methods for metal components.
- Recycle materials whenever possible.

Contact Information for Further Support

For any inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com for support and additional resources.

Thank you for following these safety instructions. Your safety and satisfaction are our top priorities. Enjoy your reloading experience with the Seater Head!