

Seater Head 8,50/.338-K9,5

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,50/.338-K9,5](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017487
- Mfr. No.: 3000054V-08.50-K09.5
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: K9,5
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-K09.5

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338K9,5. This product is designed for precise and gentle bullet seating, made from highquality brass and precisionmachined for optimal performance. To ensure your safety and the safety of others, please read this safety instruction guide carefully before using the product.

General Safety Guidelines

- Ensure that you are familiar with the basic principles of reloading and the safe handling of firearms.
- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when using this product.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of damage or wear before use.
- Follow all local laws and regulations regarding the use of reloading equipment and ammunition.

Specific Safety Precautions for Use

- Only use the Seater Head with original dies from Triebel Waffenwerkzeuge.
- Confirm that the diameter of the Seater Head matches the specifications of the bullets you are using.
- Ensure that your reloading setup is stable and secure to prevent accidents.
- Do not exceed the recommended pressure limits when seating bullets.
- Avoid distractions while using the Seater Head to maintain focus and control.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is properly set up and secured.
- Select the correct Seater Head using the tool available on the manufacturer's website: www.triebelreloading.com.
- Attach the Seater Head to your reloading die, ensuring a snug fit.

2. Usage:

- Place the cartridge case in the reloading press and ensure it is properly aligned.
- Insert the bullet into the cartridge case.
- Gradually lower the Seater Head onto the bullet, applying even pressure to seat the bullet properly.
- Check the bullet seating depth with a caliper to ensure accuracy.
- Remove the finished cartridge from the press and inspect it for proper bullet seating.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website or contact the appropriate local authorities.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the Seater Head 8,50/.338K9,5. Always prioritize safety and adhere to the guidelines provided to protect yourself and others while reloading ammunition. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk