

Seater Head 8,50/.338-K13

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,50/.338-K13](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017488
- Mfr. No.: 3000054V-08.50-K13
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: K13
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-K13

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338K13. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read this guide carefully before use to understand how to handle the Seater Head safely and properly.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose as specified by the manufacturer.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Keep the Seater Head out of reach of children and unauthorized users.
- Follow all local regulations and guidelines regarding the use of reloading equipment.
- Report any unsafe conditions or accidents involving the Seater Head to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the Seater Head.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Avoid using the Seater Head in wet or damp conditions to prevent corrosion and malfunction.
- Keep hands and other body parts clear of moving parts during operation to prevent injury.
- Ensure that the Seater Head is securely attached to the reloading press before use.
- Be aware of the potential hazards associated with reloading ammunition, including the risk of explosion or injury from improperly seated bullets.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Select the correct Seater Head using the tool available on the manufacturer's website at www.triebelreloading.com.
- Carefully attach the Seater Head to the reloading press, ensuring it is securely fastened.
- Verify that the Seater Head is properly aligned and positioned for optimal performance.

2. Usage:

- Prepare the cartridge case and bullet according to standard reloading practices.
- Place the cartridge case in the reloading press and ensure it is held securely.
- Insert the bullet into the cartridge case, aligning it with the Seater Head.
- Gradually apply pressure to the reloading press handle to seat the bullet. Monitor the process closely to ensure proper seating depth.
- After seating, check the cartridge for proper bullet alignment and seating depth.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Recycle materials where possible to minimize environmental impact.
- Do not dispose of the Seater Head in regular household waste.

Contact Information for Further Support

For safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor.

Thank you for prioritizing safety while using the Seater Head. Your attention to these guidelines will help ensure a safe and efficient reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk