

Seater Head 8,50/.338-K15

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,50/.338-K15](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017489
- Mfr. No.: 3000054V-08.50-K15
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: K15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-K15

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338K15. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully before using the Seater Head.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any signs of damage or wear before each use. Do not use if damaged.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety alerts via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that you are wearing appropriate safety gear, such as protective eyewear.
- Avoid using the Seater Head in wet or damp conditions to prevent electrical hazards.
- Do not force the Seater Head into place; it should fit smoothly into the die.
- Store the Seater Head in a dry, safe place when not in use to prevent damage.
- Be cautious of sharp edges when handling the Seater Head, as they may cause injury.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is securely mounted and stable.
- Clean the die and ensure it is free of debris before installation.
- Carefully insert the Seater Head into the die, aligning it properly.
- Tighten the die locking ring securely to hold the Seater Head in place.

2. Usage

- Adjust the seating depth according to your specifications, ensuring it is set correctly before starting.
- Place the cartridge case in the press and ensure it is properly aligned.
- Operate the press smoothly and steadily to seat the bullet gently.
- After use, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal recycling.
- Do not dispose of the Seater Head in regular household waste.
- Ensure that any packaging materials are recycled or disposed of responsibly.

Contact Information for Further Support

For further assistance or inquiries regarding safety, please refer to the manufacturer's website or contact the customer service department directly.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities. Enjoy

using your Seater Head responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk