

Seater Head 8,50/.338-R37

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,50/.338-R37
- Manufacturer: TRIEBEL
- Product no.: EU2017490
- Mfr. No.: 3000054V-08.50-R037
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R37
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R037

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 8,50/.338R37. This product is designed for precision bullet seating and is made from highquality brass. It is essential to follow the safety instructions provided in this guide to ensure safe and effective use of the product.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the Seater Head is compatible with your reloading dies.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any signs of damage before use. Do not use if damaged.
- Always wear appropriate safety gear, including eye protection, when reloading ammunition.
- Store the Seater Head in a dry, safe place when not in use.

Specific Safety Precautions for Use

- **Compatibility:** Ensure that the Seater Head is suitable for your specific reloading setup to avoid malfunctions.
- **Handling:** Handle the Seater Head carefully to avoid injury from sharp edges or points.
- **Bullets:** Use only the recommended bullet types and sizes to prevent jamming or misalignment.
- **Force:** Do not apply excessive force when seating bullets. This can lead to damage or improper bullet seating.
- **Ventilation:** Always work in a wellventilated area when reloading ammunition to avoid inhaling harmful substances.
- **Distractions:** Avoid distractions while using the Seater Head to maintain focus and safety.

Instructions for Installation and Usage

1. Preparation:

- Ensure your reloading equipment is clean and free from debris.
- Gather all necessary materials, including the Seater Head, bullets, and cases.

2. Installation:

- Insert the Seater Head into the reloading die according to the manufacturer's guidelines.
- Secure the Seater Head firmly to prevent movement during operation.

3. Usage:

- Place a cartridge case in the reloading press.
- Position the bullet on top of the case.
- Engage the press to seat the bullet gently into the case.
- Check for proper seating depth and alignment after each operation.

4. PostUse:

- Clean the Seater Head after use to remove any residue.
- Store the Seater Head in its designated case or container to prevent damage.

Disposal Instructions

- Dispose of any damaged or unusable Seater Heads in accordance with local regulations.
- Recycle materials where possible, ensuring that any hazardous materials are handled safely.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Seater Head, please refer to the manufacturer's website or customer support resources.

Conclusion

By following these safety instructions, you can ensure a safe and effective reloading experience with your Seater Head 8,50/.338R37. Always prioritize safety and consult the manufacturer for any concerns or questions.