

# Seater Head 8,50/.338-R50

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



## Attributes

- Name: [Seater Head 8,50/.338-R50](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017491
- Mfr. No.: 3000054V-08.50-R050
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R050

# Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

# Seater Head Safety Instructions

## Introduction

Thank you for choosing the Seater Head 8,50/.338R50. This product is designed to provide precise and gentle bullet seating, ensuring optimal performance for your reloading needs. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

## General Safety Guidelines

- Always ensure that you are using the product in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Inspect the product before use for any signs of damage or wear. Do not use if damaged.
- Use the product only for its intended purpose as specified by the manufacturer.
- Report any unsafe conditions or accidents related to the product to the appropriate authorities.

## Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the Seater Head.
- Ensure that the working area is clean, welllit, and free from distractions.
- Handle all components with care to avoid injury.
- Do not exceed the recommended specifications for bullet seating as stated by the manufacturer.
- Be mindful of the materials being used in conjunction with the Seater Head to avoid chemical reactions or hazards.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Select the correct seater head using the tool provided on the manufacturer's website.
- Carefully attach the Seater Head to your reloading press, following the manufacturer's instructions.
- Tighten all fasteners to ensure a secure fit.

### 2. Usage:

- Before starting, ensure that all components are correctly aligned and securely fitted.
- Place the cartridge case in the reloading press.
- Insert the bullet into the case mouth, ensuring proper alignment.
- Engage the reloading press to gently seat the bullet to the desired depth.
- Inspect the seated bullet for proper alignment and depth before proceeding with further reloading steps.

## Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Do not dispose of the product in household waste. Check for local recycling programs or hazardous waste disposal options.
- Ensure that all materials are disposed of safely to prevent environmental harm.

## **Contact Information for Further Support**

For any safety inquiries or further assistance, please refer to the manufacturer's website or contact their support team directly.

Thank you for your attention to these safety guidelines. Enjoy your reloading experience with the Seater Head 8,50/.338R50!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)