

Seater Head 8,50/.338-R55

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,50/.338-R55
- Manufacturer: TRIEBEL
- Product no.: EU2017492
- Mfr. No.: 3000054V-08.50-R055
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R55
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R055

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R55. This guide provides essential safety instructions and guidelines to ensure the safe use of this product. Please read this document carefully before using the seater head.

General Safety Guidelines

- Always use the seater head in accordance with the manufacturer's instructions.
- Ensure that the work area is clean, welllit, and free from distractions.
- Keep the seater head and all related tools out of reach of children and vulnerable individuals.
- Regularly inspect the seater head for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety goggles and gloves while handling the seater head.
- Ensure that the seater head is securely attached to the reloading press before operation.
- Avoid overtightening the seater head, as this may lead to damage or malfunction.
- Do not use the seater head for any purpose other than intended bullet seating.
- Be cautious of sharp edges and moving parts during operation.
- Do not exceed the manufacturer's recommended specifications for usage.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Select the correct seater head using the tool on the manufacturer's website.
- Carefully attach the seater head to the reloading press, ensuring it is securely fastened.
- Doublecheck that the seater head is aligned correctly for optimal bullet seating.

2. Usage:

- Prepare your cartridges and ensure they are clean and free of obstructions.
- Insert the bullet into the cartridge case and position it under the seater head.
- Slowly and steadily operate the reloading press to seat the bullet.
- Monitor the process closely to ensure proper alignment and seating depth.
- After use, clean the seater head and reloading press to maintain performance.

Disposal Instructions

- Dispose of the seater head and any associated materials in accordance with local regulations.
- Do not dispose of the seater head in regular household waste.
- Check with local authorities for proper disposal methods for metal and brass products.

Contact Information for Further Support

- For safety inquiries or additional information, please refer to the manufacturer's website or contact their

support team.

Thank you for your attention to these safety guidelines. Enjoy safe and effective reloading with your Seater Head 8,50/.338R55.