

Seater Head 8,50/.338-R65

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,50/.338-R65
- Manufacturer: TRIEBEL
- Product no.: EU2017493
- Mfr. No.: 3000054V-08.50-R065
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R65
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R065

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R65. This product is designed for precision bullet seating in reloading applications. It is essential to follow the safety instructions outlined in this guide to ensure safe and effective use.

General Safety Guidelines

- Always read and understand the product manual before use.
- Ensure that your workspace is clean and organized to prevent accidents.
- Keep the product out of reach of children and vulnerable individuals.
- Use only as intended and in accordance with the manufacturer's instructions.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Improper use may cause injury or damage to the product.
- Ensure that the Seater Head is compatible with your reloading equipment.

- **Avoiding Hazards:**

- Always wear safety glasses when handling reloading components.
- Ensure that the workspace is wellventilated to avoid inhaling dust or fumes.
- Do not exceed the recommended specifications for the Seater Head.
- Handle all components with care to prevent accidental discharge or misalignment.

- **AgeSpecific Warnings:**

- This product is not suitable for individuals under the age of 18.
- Ensure that inexperienced users are supervised by a qualified adult.

Instructions for Installation and Usage

- **Installation:**

1. Ensure that your reloading equipment is clean and free of obstructions.
2. Carefully remove the Seater Head from its packaging.
3. Align the Seater Head with the die and securely fasten it according to the manufacturer's instructions.
4. Check that the Seater Head is properly installed and does not wobble.

- **Usage:**

1. Prepare your brass cases and bullets as per your reloading procedure.
2. Insert the brass case into the reloading press.
3. Adjust the Seater Head to the desired depth for bullet seating.
4. Slowly and gently operate the press to seat the bullet, ensuring that it is aligned properly.
5. Inspect the seated bullet for proper alignment and depth before proceeding with further reloading steps.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- Check with local recycling centers for proper disposal methods for metal components.

Contact Information for Further Support

For further assistance or inquiries regarding safety and usage, please refer to the manufacturer's website or contact their customer support team.