

Seater Head 8,50/.338-R80

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,50/.338-R80
- Manufacturer: TRIEBEL
- Product no.: EU2017494
- Mfr. No.: 3000054V-08.50-R080
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R80
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R080

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for purchasing the Seater Head 8,50/.338R80. This guide provides important safety information and instructions to ensure the safe use of this product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Always ensure that you are using the Seater Head in compliance with the manufacturer's instructions.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head only with compatible equipment and original dies from Triebel Waffenwerkzeuge.
- Regularly inspect the Seater Head for any signs of wear or damage before each use.
- Do not use the Seater Head if it is damaged or if any parts are missing.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the work area is clean and free from distractions.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the Seater Head.
- Avoid direct contact with the Seater Head when it is in use to prevent injury.
- Do not exceed the recommended specifications for the Seater Head.
- Follow all safety protocols when reloading ammunition to prevent accidents.

Instructions for Installation and Usage

1. Installation

- Ensure the reloading press is securely mounted and stable before installation.
- Carefully follow the manufacturer's instructions to install the Seater Head.
- Make sure the Seater Head is properly aligned with the reloading die.

2. Usage

- Select the correct seater head using the tool on the manufacturer's website: www.triebelreloading.com.
- Check that the bullet is properly seated in the case before proceeding.
- Maintain a steady and controlled motion when seating bullets to ensure accuracy.
- After use, clean the Seater Head to maintain its performance and longevity.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or contains hazardous materials.
- Contact your local waste management authority for specific disposal guidelines.

Contact Information for Further Support

For safety inquiries and support, please refer to the manufacturer's website or contact their customer service directly.

By following these safety instructions, you can ensure a safer and more effective experience with the Seater Head 8,50/.338R80. Thank you for prioritizing safety in your reloading practices.