

Seater Head 8,50/.338-R90B

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,50/.338-R90B
- Manufacturer: TRIEBEL
- Product no.: EU2017496
- Mfr. No.: 3000054V-08.50-R090B
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R90B
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R090B

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R90B from TRIEBEL. This product is designed for precision bullet seating in reloading applications. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Always wear appropriate safety gear, including eye protection, when handling reloading tools and components.
- Keep the Seater Head and all reloading equipment out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- If you notice any irregularities or defects, do not use the product and contact the manufacturer for assistance.

Specific Safety Precautions for Use

- Always follow the manufacturer's guidelines for using the Seater Head to avoid accidents.
- Ensure that the Seater Head is securely attached to the reloading die before use.
- Do not exceed the recommended working pressure or force when seating bullets.
- Use appropriate lubrication on the bullets and cases to avoid excessive force during seating.
- Avoid distractions while using the Seater Head to maintain focus and precision.
- In case of an accident or injury, seek medical attention immediately.

Instructions for Installation and Usage

1. Installation:

- Start by ensuring that your reloading press is clean and free of debris.
- Carefully remove the Seater Head from its packaging.
- Attach the Seater Head to the reloading die by threading it securely into place.
- Ensure that it is tightened according to the manufacturer's specifications.

2. Usage:

- Prepare your cartridges and bullets according to your reloading recipe.
- Place the cartridge case into the reloading press.
- Insert the bullet into the case mouth.
- Operate the reloading press smoothly to seat the bullet gently into the case.
- Check for proper bullet seating depth using a caliper or similar measuring tool.
- Repeat the process for each cartridge, ensuring that the Seater Head remains properly aligned.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- If you need to dispose of the product due to damage or wear, contact local waste management facilities for guidance on safe disposal.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please refer to the manufacturer's website at www.triebelreloading.com. You can find resources and contact information for assistance.

Thank you for following these safety instructions. Your safety and satisfaction are our top priorities. Enjoy your reloading experience with the Seater Head 8,50/.338R90B!