

Seater Head 8,50/.338-R90C

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,50/.338-R90C](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017497
- Mfr. No.: 3000054V-08.50-R090C
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R90C
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R090C

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R90C. This guide provides essential safety instructions and usage guidelines to ensure your safe and effective use of the product. Please read this document carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Always wear appropriate personal protective equipment (PPE) such as safety goggles and gloves when handling reloading equipment.
- Keep the Seater Head out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of damage or wear before use. Do not use if damaged.
- Do not modify or alter the Seater Head in any way, as this may compromise its safety and performance.
- Be aware of your surroundings and ensure that your workspace is free of clutter and hazards.

Specific Safety Precautions for Use

- Handle the Seater Head with care to avoid injury.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Ensure that the bullet seating process is performed in a wellventilated area to avoid inhalation of any dust or particles.
- Follow the recommended torque specifications when attaching the Seater Head to the reloading die.
- Do not exceed the recommended bullet seating depth as specified in the die instructions.
- Be cautious of hot surfaces when using the Seater Head in conjunction with heated equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Select the appropriate Seater Head for your reloading die.
- Carefully attach the Seater Head to the die, ensuring a secure fit. Use the manufacturer's recommended torque specifications.
- Doublecheck that the Seater Head is properly aligned and locked in place before proceeding.

2. Usage:

- Prepare your cartridges and bullets according to standard reloading practices.
- Insert the cartridge case into the reloading press and ensure it is securely held.
- Place the bullet onto the case mouth, ensuring proper alignment.
- Gradually lower the Seater Head onto the bullet to begin the seating process.
- Monitor the seating depth and adjust as necessary, following the die instructions.
- Once the bullet is seated, inspect the cartridge for proper seating and alignment.

Disposal Instructions

- Dispose of the Seater Head according to local regulations for metal recycling.
- Do not dispose of the Seater Head in regular household waste.
- Ensure that any damaged or unusable components are safely disposed of to prevent injury.

Contact Information for Further Support

For any questions or safety inquiries regarding the Seater Head, please refer to the manufacturer's website or contact their customer support. It is important to have access to expert guidance when using reloading equipment.

By following these safety instructions and guidelines, you can ensure a safe and effective reloading experience with the Seater Head 8,50/.338R90C. Always prioritize safety and stay informed about best practices in reloading.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk