

Seater Head 8,50/.338-R110

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,50/.338-R110](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017498
- Mfr. No.: 3000054V-08.50-R110
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R110
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R110

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R110. This guide provides important safety instructions and guidelines to ensure the safe use of this product. Please read this document carefully before use to understand the necessary precautions and procedures.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the Seater Head and all reloading components out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Follow all local laws and regulations regarding ammunition reloading.

Specific Safety Precautions for Use

- Do not exceed the recommended specifications for bullet diameter and radius when using the Seater Head.
- Ensure that the Seater Head is securely attached to the reloading press before operation.
- Avoid using the Seater Head with damaged or improperly sized cartridges, as this may lead to dangerous malfunctions.
- Do not use excessive force when seating bullets to prevent damage to the Seater Head and ensure proper alignment.
- Always work in a wellventilated area to avoid inhaling any potentially harmful substances.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Remove any existing seater heads from the reloading press.
- Carefully attach the Seater Head 8,50/.338R110 to the press, ensuring it is tightened securely.
- Verify that the Seater Head is aligned correctly with the die.

2. Usage:

- Select the appropriate bullet and cartridge combination as per the specifications.
- Place the cartridge in the reloading press and ensure it is seated properly.
- Gently lower the press handle to seat the bullet. Monitor the process to ensure that the bullet is aligned correctly.
- After seating, inspect the cartridge for proper bullet seating and alignment.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not throw the Seater Head in regular household waste.
- Contact your local waste management facility for proper disposal methods for brass and metal components.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or its safe usage, please refer to the manufacturer's website for additional resources and support.

By following these guidelines, you can ensure a safe and effective reloading experience with the Seater Head 8,50/.338R110. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk