

Seater Head 8,50/.338-R125

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,50/.338-R125
- Manufacturer: TRIEBEL
- Product no.: EU2017499
- Mfr. No.: 3000054V-08.50-R125
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R125
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R125

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R125 by TRIEBEL. This guide provides essential safety instructions to ensure the safe use, installation, and disposal of the product. Following these guidelines will help you achieve optimal performance while minimizing risks.

General Safety Guidelines

- Always read the manufacturer's instructions before use.
- Ensure the product is compatible with your reloading equipment.
- Use the product only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - The Seater Head can pose risks if not used correctly, including:
 - Injury from improper handling.
 - Damage to reloading equipment.
 - Inaccurate bullet seating affecting cartridge performance.
- **Avoiding Hazards:**
 - Always handle the Seater Head with care.
 - Ensure your workspace is clean and organized to prevent accidents.
 - Use appropriate personal protective equipment (PPE), such as safety glasses and gloves.
 - Never exceed the recommended specifications for the Seater Head.
- **AgeSpecific Warnings:**
 - This product is not intended for use by individuals under the age of 18 without adult supervision.
 - Ensure that inexperienced users are guided by knowledgeable individuals.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure your reloading press is turned off and unplugged.
 2. Carefully remove the existing seater head from your die set.
 3. Align the Seater Head 8,50/.338R125 with the die and install it securely.
 4. Tighten the seater head according to the manufacturer's specifications.
- **Usage:**
 1. Verify that the Seater Head is properly installed before reloading.
 2. Use the tool available on the manufacturer's website to select the correct seater head for your needs.
 3. When seating bullets, maintain a steady and gentle pressure to ensure proper alignment.
 4. Regularly check cartridge concentricity to ensure consistent performance.

5. Store the Seater Head in a safe and dry place when not in use.

Disposal Instructions

- Dispose of the Seater Head according to local regulations.
- Do not throw the product in general waste.
- If the product is damaged or no longer usable, contact your local waste management for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the EU contact point provided by the manufacturer. Always ensure you have the latest information regarding recalls or safety updates from the Safety Gate platform.

By following these guidelines, you can ensure a safe and effective reloading experience with the Seater Head 8,50/.338R125. Thank you for your attention to safety!