

Seater Head 8,50/.338-R150

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,50/.338-R150
- Manufacturer: TRIEBEL
- Product no.: EU2017500
- Mfr. No.: 3000054V-08.50-R150
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R150
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R150

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 8,50/.338R150. This product is designed for precision bullet seating, ensuring optimal performance and accuracy. To ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR), please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure the Seater Head is compatible with your reloading equipment before use.
- Always handle the Seater Head with care to prevent injury.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of damage or wear before use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when using the Seater Head.
- Avoid using the Seater Head if you are tired or under the influence of substances that may impair your judgment.
- Do not exceed the recommended specifications for the Seater Head, including the diameter and radius.
- Ensure that the Seater Head is securely attached to your reloading die before use.
- Follow the manufacturer's guidelines for bullet types and weights to prevent malfunctions.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Remove the existing seater head from your reloading die if applicable.
- Carefully insert the Seater Head into the die, ensuring it is aligned properly.
- Tighten the seater head securely using the appropriate tools without overtightening.

2. Usage:

- Set up your reloading press according to the manufacturer's instructions.
- Select the correct bullet type and weight for use with the Seater Head.
- Place a cartridge case into the press and ensure it is properly positioned.
- Operate the press slowly and steadily to seat the bullet gently.
- Regularly check for proper bullet seating and cartridge concentricity during the process.

Disposal Instructions

- Dispose of the Seater Head responsibly in accordance with local regulations.
- Do not throw the Seater Head in regular household waste.
- If the Seater Head is damaged or no longer usable, consider recycling options available in your area.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's website at www.triebelreloading.com. Ensure you have the product details ready for a more efficient response.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.