

Seater Head 8,50/.338-R200

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,50/.338-R200](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017501
- Mfr. No.: 3000054V-08.50-R200
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R200
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R200

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R200. This guide provides essential safety instructions and usage information to ensure safe and effective operation of your product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure the Seater Head is used only for its intended purpose as described in this manual.
- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when handling reloading equipment.
- Keep the Seater Head and all related equipment out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear, damage, or malfunction before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Ensure that the Seater Head is securely attached to the reloading press before use.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head and ensure accurate seating.
- Do not exceed the recommended caliber specifications for the Seater Head.
- Always follow the manufacturer's guidelines for bullet and cartridge specifications.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged.
- Carefully remove the Seater Head from its packaging.
- Align the Seater Head with the corresponding die in your reloading press.
- Securely tighten the Seater Head in place using the appropriate tools.

2. Usage:

- Prepare your cartridges and bullets according to standard reloading practices.
- Place the cartridge in the die and position the bullet on top of the cartridge.
- Engage the reloading press to seat the bullet into the cartridge.
- Check for proper bullet seating depth and alignment. Adjust as necessary.
- After use, clean the Seater Head to remove any debris or residue.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For additional support or inquiries regarding safety, please refer to the manufacturer's website or contact your local distributor.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and effective reloading experience with the Seater Head 8,50/.338R200.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk