

Seater Head 9,00/.358-K15,5

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 9,00/.358-K15,5](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017503
- Mfr. No.: 3000054V-09.00-K15.5
- Diameter (in): 0.366
- Diameter mm: 9,00
- Radius: K15,5
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.00-K15.5

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,00/.358K15,5 for your reloading needs. This product is designed to provide precise and gentle bullet seating, ensuring optimal performance in your reloading process. Please read this safety instruction guide carefully to ensure safe and effective use.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Always follow the manufacturer's instructions and guidelines during use.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the Seater Head regularly for signs of wear or damage.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Check for updates regarding product recalls on the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible Triebel original dies.
- Do not exceed the manufacturer's recommended specifications for diameter and radius.
- Wear appropriate safety gear, including eye protection, when using the Seater Head.
- Ensure that your workspace is clean and organized to prevent accidents.
- Avoid using the Seater Head in damp or wet conditions to prevent corrosion.
- Do not modify the Seater Head in any way, as this may compromise safety and performance.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and components needed for reloading.
- Ensure your workspace is welllit and free from distractions.

2. Installation:

- Select the correct Seater Head using the tool on the manufacturer's website.
- Carefully attach the Seater Head to the reloading press according to the manufacturer's instructions.
- Ensure that the Seater Head is securely fastened before use.

3. Usage:

- Place the cartridge case in the reloading press.
- Align the bullet with the Seater Head and ensure proper positioning.
- Slowly and steadily apply pressure to seat the bullet into the cartridge case.
- Check for proper bullet seating depth and alignment after each operation.

4. PostUsage:

- Remove the Seater Head from the reloading press when not in use.
- Clean the Seater Head to remove any residue or debris.
- Store the Seater Head in a dry and safe location.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or worn.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or safety instructions, please refer to the manufacturer's website or contact your local distributor for assistance.

Thank you for prioritizing safety in your reloading practices. Enjoy your experience with the Seater Head and achieve optimal results in your ammunition crafting.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk