

Seater Head 9,30/.366-K15

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,30/.366-K15
- Manufacturer: TRIEBEL
- Product no.: EU2017505
- Mfr. No.: 3000054V-09.30-K15
- Diameter (in): 0.366
- Diameter mm: 9,30
- Radius: K15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.30-K15

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,30/.366K15. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully to understand how to use, install, and dispose of the Seater Head safely.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any damages or defects before use. Do not use if damaged.
- Ensure that all equipment used with the Seater Head is compatible and in good working condition.
- Do not modify the Seater Head in any way. Unauthorized modifications can lead to safety hazards.
- Store the Seater Head in a dry, safe place when not in use to prevent damage or accidents.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the Seater Head.
- Ensure that the workspace is clean and free of obstructions to prevent accidents.
- Be aware of the potential risks associated with reloading ammunition and follow all relevant safety practices.
- Do not exceed the recommended specifications for bullet seating as outlined by the manufacturer.
- Avoid using the Seater Head in wet or humid conditions to prevent rust and corrosion.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and components for reloading.
- Ensure that your reloading press is securely mounted and stable.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Attach the Seater Head to the reloading press according to the manufacturer's instructions.
- Ensure that the Seater Head is properly aligned and securely fastened.

3. Usage:

- Load the appropriate cartridge case into the reloading press.
- Place the bullet into the cartridge case as per the specifications for diameter and radius.
- Gradually apply pressure to the press handle to seat the bullet gently and accurately.
- Monitor the process to ensure that the bullet is seated correctly and that there are no obstructions.

4. PostUse:

- After use, clean the Seater Head to remove any residue or debris.
- Store the Seater Head in a safe location, away from moisture and potential hazards.

Disposal Instructions

- Dispose of any packaging materials responsibly, following local recycling guidelines.
- If the Seater Head is no longer usable, dispose of it in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any safety inquiries or further support, please refer to the manufacturer's website or contact your local distributor. It is essential to have access to reliable information regarding the safe use of your product.

By following these safety instructions, you contribute to a safer reloading environment and ensure the longevity and effectiveness of your Seater Head. Thank you for your attention to safety.